

ASSEMBLY INSTRUCTION **Profi-EXT**



Please note:

SunProCool® Profi-EXT Frame Assembly:

→ The SunProCool® Profi-EXT Frame is attached to the **outside of the window**. (Inside is also possible, but with less protection.)

The ambient temperature must be $> 10^{\circ}\text{C}$, for the adhesive to function at its full capacity.

SunProCool® Profi-EXT Frame Cleaning:

- **Use cotton cloths only**
- **Do not use microfiber cloths**



Testfit

Hold the SunProCool® Profi-EXT Frame onto the glass surface (do not glue it yet) and check if it fits, including the surrounding brush. (Do not remove the protective film yet!)



Clean glass surface

Clean the glass surface thoroughly with a glass cleaner! (Dirt and dust particles must be removed completely)



Clean the glue areas

Thoroughly clean the glue areas on the glass surface.

The surface must be free of grease and silicone.



Optional: Glue the mounting aid

At the bottom of the window frame, adhere the enclosed mounting aid pads.



Preparation for installation of the SunProCool[®] Profi-EXT frame

Remove the protective tape from the adhesive plates of the SunProCool[®] Profi-EXT frame.



Assembly

Position the SunProCool® Profi-EXT Frame slightly tilted at the bottom of the window and press it to the glass surface from bottom up to top and stick it with adhesive pads.



Repress

At the level of the adhesive pads, press the SunProCool® Profi-EXT Frame firmly to the window using your hand. This increases the adhesive effect of the adhesive pads or the adhesive plates.



Remove protective film

Carefully peel off flat the protective film.



Important !!!

SunProCool® Profi-EXT frame
Do not disassemble for 24 hours!
The adhesive pads or plates require approximately 24 hours to develop maximum adhesive strength.

Congratulation, you are now using an innovative sun and heat protection for your rooms.



MADE IN GERMANY

Don't forget:

During the colder months the SunProCool® Profi-EXT Frame can be removed, so that sunbeams may heat the rooms.



Optional: Dismantling

The SunProCool® systems can be carefully removed and stored by unscrewing the black knurled screws.

www.sunprocool.com

