

# ASSEMBLY INSTRUCTION **Easy-INT**



Please note:

## **SunProCool**® **Easy-INT** Assembly:

→ The SunProCool® Easy-INT is attached to the **inside of the window**.

**The ambient temperature** must be  $> 10^{\circ}\text{C}$ ,  
for the adhesive to function at its full capacity.



## **SunProCool**® **Easy-INT** Cleaning:

- **Use cotton cloths only**
- **Do not use microfiber cloths**



## **Testfit**

Hold the SunProCool® Easy-INT onto the glass surface (do not glue it yet) and check if it fits, including the surrounding brush. (Do not remove the protective film yet!)



## **Clean glass surface**

Clean the glass surface thoroughly with a glass cleaner! (Dirt and dust particles must be removed completely)



## **Clean the glue areas**

Thoroughly clean the glue areas on the glass surface.

The surface must be free of grease and silicone.



## **Optional: Glue the mounting aid**

Stick the enclosed support pads to the lower window frame at a distance of approximately 3-4 mm from the window glass.



## **Assembly preparation**

Remove the inner protective film  
Remove the protective tape from the adhesive pads of the SunProCool® Easy-INT pads.



## Assembly

Position of the SunProCool® Easy-INT slightly tilted at the bottom of the window between the mounting aid and the glass surface. Press and adhere it from bottom to top. Applying additional pressure at the pad positions will increase the adhesion of the adhesive pads.



## Remove protective film

Carefully peel off flat the protective film. Press down again at the pad positions.

## Remove Mounting aid

Carefully peel off the mounting aid from the window-frame



## Important !!!

SunProCool® Easy-INT System  
Do not disassemble for 24 hours!  
The adhesive pads need approximately 24 hours to develop maximum adhesive strength.

**Congratulation, you are now using an innovative sun and heat protection for your rooms.**



**MADE IN GERMANY**

**Don't forget:**

During the colder months the SunProCool<sup>®</sup> Easy-INT can be removed, so that sunbeams may heat the rooms.



**Easy disassembly:**

Using the disassembly tool, the SunProCool<sup>®</sup> Easy-INT system can be removed and stored.

**[www.sunprocool.com](http://www.sunprocool.com)**

